

TOSHIBA

SERVICE MANUAL

AIR-CONDITIONER




SPLIT TYPE

Indoor Unit

RAS-18J2KVSG-E
RAS-B22J2KVSG-E
RAS-B24J2KVSG-E
RAS-18N4KVSG-E
RAS-B22N4KVSG-E
RAS-B24N4KVSG-E

Outdoor Unit

RAS-18J2AVSG-E
RAS-22J2AVSG-E
RAS-24J2AVSG-E




R32

INVERTER




13. EXPLODED VIEWS AND PARTS LIST

13-1. Indoor Unit



Location No.	Part No.	Description	Location No.	Part No.	Description
201	43T00778	FRONT PANEL ASSY (FOR RAS-18,B22J2KVSG-E/N4KVSG-E)	219	43T39381	MOTOR BAND BACK
201	43T00779	FRONT PANEL ASSY (FOR RAS-B24J2KVSG-E/N4KVSG-E)	220	43T39382	MOTOR BAND FRONT
202	43T00715	CAP SCREW	221	43T44664	REFRIGERATION CYCLE ASSY (FOR RAS-18J2KVSG-E/N4KVSG-E)
203	43T09586	GRILLE OF AIR INLET ASSY	221	43T44665	REFRIGERATION CYCLE ASSY (FOR RAS-B22J2KVSG-E/N4KVSG-E)
204	43T80358	AIR FILTER	221	43T44666	REFRIGERATION CYCLE ASSY (FOR RAS-B24J2KVSG-E/N4KVSG-E)
205	43T03405	BACK BODY ASSY	222	43T19333	HOLDER, SENSOR
206	43T22353	VERTICAL LOUVER ASSY	223	43T49045	PIPE, SHIELD
207	43T03406	COVER MOTOR VT	224	43T49043	HOLDER, PIPE
208	43T21434	STEPPING-MOTOR	225	43T82008	PLATE, INSTALLATION
209	43T72353	DRAIN PAN ASSY	226	43T62360	TERMINAL COVER ASSY
210	43T22367	HORIZONTAL LOUVER	227	43T66402	WIRELESS REMOCO
211	43T70321	DRAIN HOSE	228	43T83305	HOLDER, REMOTE CONTROL
212	43T79322	DRAIN CAP	229	43T60481	CORD MOTOR LOUVER RIGHT
213	43T21478	MOTOR; STEPPING	230	43T60482	CORD MOTOR LOUVER LEFT
214	43T21495	FAN-MOTOR	231	43T60483	CORD MOTOR LOUVER HR
215	43T20357	CROSS FLOW FAN ASSY	232	43T91333	PACKING SLEEVE
216	43T39385	BASE BEARING	233	43T91397	PACKING CUSHION RIGHT
217	43T22312	BEARING ASSY, MOLD	234	43T91398	PACKING CUSHION LEFT
218	43T39383	MOTOR COVER (FOR RAS-18,B22J2KVSG-E/N4KVSG-E)			
218	43T39384	MOTOR COVER (FOR RAS-B24J2KVSG-E/N4KVSG-E)			

13-2. Indoor Unit (Part-E)



Location No.	Part No.	Description	Location No.	Part No.	Description
401	43T50393	TEMPERATURE SENSOR	406	43T6W722	PC BOARD ASSY (FOR RAS-B22J2KVSG-E/N4KVSG-E)
402	43T6V673	TERMINAL(5P-TF)	406	43T6W724	PC BOARD ASSY (FOR RAS-B24J2KVSG-E//N4KVSG-E)
403	43T50392	SENSOR,THERMOSTAT	407	43T60502	HOUSING-WiFi
404	43T62340	CORD-CLAMP	408	43T50306	TEMPERATURE SENSOR (FOR RAS-B22, B24J2KVSG-E/N4KVSG-E)
405	43T6W727	PC BOARD ASSY : WRS-LED			
406	43T6W721	PC BOARD ASSY (FOR RAS-18J2KVSG-E/N4KVSG-E)			